folding your stroller:

1 unlock canopy



push safety lock lever down and pull up on the folding handle at the same time



3 push forward and down



4 throw over your shoulder and GO!



reattaching the storage basket:





water and mild soap.

Clean minor stains on fabric with cold

- Clean plastic and metal surfaces with a soft damp cloth. Air dry. Do not use abrasive cleaners or solvents. Do not use bleach.
- Check seat pad harness and crotch straps weekly to ensure they are properly secured to frame.

mer Infant stands behind all of its products. If you are not completely satisfied or have any questions, please contact our Consumer Relations Team at 1-800-268-6237 or www.summerinfant.com/contact

(For Europe call (0) 144 250 5000 or



Summer Infant, Inc. 1275 Park East Drive Woonsocket, RI 02895 USA 1-800-268-6237

Summer Infant Canada I 1055 Middlegate Road, Unit 2 Mississauga, Ontario L4Y 3Y4 MADE IN CHINA.

©2012 Summer Infant, Inc. Colors and styles may vary. Please retain for future reference

04/13





INSTRUCTION MANUAL

Please read the following instructions and warnings carefully before using the stroller. Keep this instruction manual for future reference. No tools required.


For Technical Support Call 1-800-268-6237 Keep small parts away from children.




⚠ WARNING:

Read and follow all warnings and instructions. Failure to do so could result in serious injury or death.


- Maximum weight of child: 50 lbs. (22.7 kg)
- NEVER leave child unattended.
- Avoid serious injury from falling or sliding out. ALWAYS use safety harness.
- When making adjustments to the product ALWAYS ENSURE that all parts of a child's body are clear of any moving parts of the product.
- Care must be taken when folding and unfolding the product to prevent finger entrapment.
- DO NOT carry additional children, goods or accessories in or on this product except as recommended in the manufacturer's instructions.
- TO AVOID INJURY TO YOUR CHILD, DO NOT USE STORAGE BASKET AS A CHILD CARRIER.
- DO NOT hang items on handle bar or place them on the canopy, as they can tip stroller over and injure child.
- DO NOT OVERLOAD STORAGE BASKET. MAXIMUM 10 lbs. (4.5 kg).
- DO NOT overload the storage pocket and cup holder. MAXIMUM 2 lbs. (0.9 kg). Excessive weight may cause the stroller to become unstable or tip over.
- Do not place hot liquids in the cup holder. Spills can burn your child.
- Do not carry or roll stroller on stairs or escalators with child in it.
- Do not use the strollers if any part is lost or damaged.
- See instructions for additional warnings.



assembly instructions:




tightening and loosening child restraint:



using sun visor:










press button down to lock brake

press button up to lock swivel



press button up to unlock brake



press button down to unlock swivel

reclining the seat:


1 to raise backrest up hold backrest and lift up to desired position



1 to lower backrest press red lever, lower backrest to desired position and lock in place



adjusting shoulder harness position:



locking/unlocking the child restraint:



 press the lock-out bar down with your foot




align rear wheels and push onto frame




NOTE: Before use, ensure that the stroller locking mechanism is secured.

align front wheels making sure locations of lock pedal is up and push onto frame




are both securely attached.

6 line up cupholder with mounting post and push down



Tug on each wheel to ensure they are both securely attached.



slide canopy onto frame mounts and attach velcro (both sides) 3